


For this part you will need:

- 28x M8 Nuts
- 28x M8 Washers
- 6x M8x370mm, Threaded Rods
- 4x frame-vertex-foot printed pieces
- 2x frame-vertex printed pieces
- 2x bar-clamp printed pieces

You will need something to measure with or you can use a jig that's 290mm long. You will also need a couple 13mm wrenches to tighten things up. We will be making two of these equilateral triangles:



Copyright © 2015 by The McGraw-Hill Companies, Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of The McGraw-Hill Companies, Inc.





[Continue to the the next step where we get the front part of the frame ready](#)